




4ft Football Table

Wood Finish

Read all precautions and instructions in this manual before using this equipment.





























Keep this manual for future reference.


Note: The product photo is for reference only and may differ slightly from the actual product.




Model: SGC2375

Parts list


1  1x Soccer Playfield	2  2x Long side element	3  2x Short side element	4  24x 6x30mm Bolt	5  24x Washer Screw	6  2x Support Rod
7  2x Cup Holder	8  2x Support Brace	9  2x Left Leg	10  2x Right Leg	11  4x Leg Leveler	12  26x 3.5x18 mm Round Head Screw
13  11x Player (Red)	14  11x Player (Yellow)	15  2x Soccer Ball	16  2x 2 Player Rod	17  4x 3 Player Rod	18  2x 5 Player Rod
19  4x Stop Ring	20  16x Rubber Bumper	21  8x Hand Grip	22  8x End Cap	23  2x Chrome Bar	24  2x Scorers
25  4x 3.5x28 mm Screw	26  8x 3.5x12 mm Screw	27  4x Support rod Nut	28  1x Support Tool		




Push the upturned playing field (No. 1) with the side walls (No. 2) and (No. 3) together and then fasten them.




Attach the support beams under the playing field.





Attach the support legs, crossbars, and feet.





Push the players onto the bar, and don't forget to attach a stop ring (No. 19) and a rubber bumper (No. 20) on each side.



Attach the handle to one side and the cap to the other.

Attach the two goal counters and cup holders as shown.

