

# DynaSpace



## Portable Basketball Hoop

Read all precautions and instructions in this manual before using this equipment.


Keep this manual for future reference.

*Note: The product photo is for reference only and may differ slightly from the actual product.*



Model: SGC2340

# ACCESSORIES LIST



1




10pcs

2



3



4



5



6



7



8



9



10




11




M8\*30


12



Y



X



W



M6\*50

13



M6\*45

14



M6\*16

15







M8\*65

16

# INSTALLATION STEPS

## Needed Parts



Insert ③ into slot ④, then insert ③ and ④ into the fixing block (⑤) and press it into the slot. Finally, attach the fixing block (⑤) to the backboard (①) and fix it to the backboard (①⑥) and upper rod (①) with screws (W)



# INSTALLATION STEPS

## Needed Parts



7



8



9



10



11

Y

X



M6\*50

13



M6\*45

14



M6\*16

15

10

M8\*30

12


1




2




3



4



5




# INSTALLATION STEPS

## Needed Parts



10pcs

②




④



⑥

①


Fix ⑥ onto ④ with ②



# INSTALLATION STEPS

## FINAL INSTALLATION

When using X and W tubes, the lifting height is 108-143cm; When using X, Y, and W tubes, the lifting height is 152-210cm



# BASKETBALL HOOP DISPLAY

## FINAL INSTRUCTIONS



- Please use the pole that comes with the product
- **Note:** The adjustable height of the basketball hoop is 1.08-2.10m
- Before use, fill the base with water or sand