


DynaSpace



www.spacegeneral.co.nz

PARTES	
A x5	I x1
B x1	J x4
C x1(L/R)	K x2
D x1	L x4
E x1	M x4
F x1	N x6
G x1	O x1

INSRTUCCTIONS	
①	②
③	④
⑤	⑥