




open concept
















Important:


Please read through instructions carefully
Before assembly and keep for future reference.



Hardware	Ctn No.	1
----------	---------	---





<div>A1 x 1</div>  <div>1649x460x23mm</div>	<div>A2 x 1</div>  <div>1649x460x23mm</div>	<div>B1 x 1</div>  <div>1628x356x23mm</div>	<div>B2 x 1</div>  <div>1628x356x23mm</div>
<div>C1 x 1</div>  <div>1601x354.5x20mm</div>	<div>C2 x 1</div>  <div>1601x354.5x20mm</div>	<div>D x 1</div>  <div>762x462x20mm</div>	<div>E x 2</div>  <div>757x320x20mm</div>
<div>F x 1</div>  <div>757x435x35mm</div>	<div>G x 4</div>  <div>364x378x20mm</div>	<div>H x 1</div>  <div>1359x376x20mm</div>	<div>I x 1</div>  <div>757x400x20mm</div>
<div>J x 1</div>  <div>Ø16*378mm</div>			




(1) - Attach (A) to (E) as below shown.

Make sure the holes are nearest to outside otherwise will affect door assembling.




Push and bend the tab.


(2) - Attach (B1) & (B2) to (A) & (E) as below shown.




(3) - Attach (F) to (A) & (B) & (E) as below shown.





(4) - Attach (D) to (A) & (B) as below shown.




(5) - Attach (I) to pre-assembled unit as below shown.




(5) - Attach (H) to pre-assembled unit as below shown.




(6) - Attach (G) to pre-assembled unit as below shown.




(7) - Attach (J) to (A1) & (H) as below shown.




(8) - Attach (2) & (3) to pre-assembled unit as below shown.







(9) - Attach (C1) & (C2) to pre-assembled unit as below shown.



(10) - Attach (6) to (C1) & (C2) as below shown.



(11)



Gaps may appear between the top of the doors and the frame if the item is not on level ground; use the plastic foot cover to level.

Open Concept

Great Job! You're done it

Don't forget to share how it looks in
your space and tag us on Instagram

@spacegeneralnz

www.spacegeneral.co.nz