


Space General

www.spacegeneral.co.nz



Assembly Instructions


Thank you for your purchase.

Please follow the instructions below for correct assembly.

Safety and Care Advice

IMPORTANT - Please Read This Instruction Carefully Before Assembly.


- Check you have all the components and tools listed on page 3.
- Remove all settings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before assembly.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its intended position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit.
- Parts of the assembly will be easier with 2 people.
- Do not use power drill/drivers for assembly, or the unit may be damaged.
- Dispose of all packaging carefully and responsibly.



CARE and MAINTENANCE

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal center.


General Hints & Tips



Components and Tools

IMPORTANT - Please Check If You Have All The Components and Tools.


Note: The quantities below are the correct amount to complete the assembly. In some cases more pieces may be supplied than are required.



Components and Tools

IMPORTANT - Please Check If You Have All The Components and Tools.

Note: The quantities below are the correct amount to complete the assembly. In some cases more pieces may be supplied than are required.

A=54  Peg M6*34mm	B=54  Lock M15*12mm	C=42  Dowel M6*30mm	D=32  Screw M3.5*14mm	E=4  Screw M4*38	F=6  Plastic Feet
G=20  16*13*10mm	H=50  Shelf Panel Pin M5*18mm	J=16  Insert Door Hinge	K=1  Ø60	M=2  Wall bracket	
P=1  Wall bracket					

1OF3 | **1, 9, 10, 11, 21, 23.**

2OF3 (8, 12, 13, 14, 15, 16, 17, 18X2, 19, 20X3, 22).

3OF3 **②,③,④,⑤,⑥,⑦, FITTING KIT.**


Assembly Instruction

Step 1

A=10




Peg



Step 2


A=4 C=4

Peg




Dowel

J=2




Turn Over
180°



Assembly Instruction


Step 3

A=8	C=6
Peg	Dowel
J=2	F=2
Plastic Feet	



Step 4


C=4	D=4
Dowel	Screw M3.5*14mm
M=2	
Full Overlay Door Hinge	



Assembly Instruction


Step 5

A=6 C=4




Peg Dowel

J=6




Step 6

A=12 C=8



Peg Dowel

J=6




Assembly Instruction

Step 7

A=2 C=12


Peg Dowel



Step 8

A=4 C=4

Peg Dowel




Assembly Instruction

Step 9

B=4



Lock





Step 10

B=2



Lock




Assembly Instruction

Step 11


B=12



Lock



Step 12




Assembly Instruction

Step 13


B=6



Lock



Step 14




Assembly Instruction

Step 15

F=4



Plastic Feet





Step 16

B=2



Lock




Assembly Instruction

Step 17

B=4




Lock



Step 18

Step 18




Assembly Instruction

Step 19

B=6



Lock




Step 20

B=10



Lock




Assembly Instruction

Step 21

A=8



Peg




Assembly Instruction

Step 22

B=8



Lock



Assembly Instruction

Step 23

E=4 D=20




Screw Screw

G=20



16*13*10




Assembly Instruction

Step 24

K=1




Ø60




Assembly Instruction

Step 25

D=4 H=50





Screw
M3.5*14mm





STEP 26





Customer Attention:
To align doors and control gap in between doors.
Product doors may need adjusting during
and after assembly.
This can be done by adjusting appropriate screws.
See below illustration.



Vertical door adjustment:
Loosen both screws on all hinges and lift the
door to the desired height.
This allows an even space at the top and
bottom between the door and frame



Lateral Door Adjustment:
If door is hinge bound, (rubbing on frame as you
close or open door) loosening screw shown and
move the door in appropriate direction. (In or out)




D 4PCS

Horizontal Door Adjustment:
Rotate Screw clock wise or anti clockwise. This
will produce an even gap between doors and frame.
after adjusting, you find the doors are in alignment,
you can fasten that hinge with 2 screws





Assembly Instruction

Step 27



OK

P=1



Awesome! You did it!

We'd love to see how it looks in your space—share your setup and tag us on

Instagram @spacegeneralnz

Visit us at www.spacegeneral.co.nz.